





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	61070060	Screw				
2	2	61170014	Spacer				
3	2	61070065R	Piston ring				
4	1	61070066	Piston pin				
5	2	61070067	Ring				
6	1	61070107	Piston assy				
7	1	61070072A	Complete cylinder Ø34				
8	1	61070059	Gasket				
9	1	61070033	Gasket				
10	1	58040332R	Muffler				
11	1	61070055R	Plate				
12	2	3806027	Screw				
13	1	61070026BR	Cover				
14	2	4191069B	Plate				
15	2	3960030	Screw				
16	1	58040048	Lock				
17	3	3916004R	Washer				
18	4	3909005	Screw				
19	4	61070063	Screw				
20	1	61070075	Seal ring				
21	1	61070061R	Crankcase				
22	1	3025019	Ring				
23	2	3034009R	Bearing				
24	1	61070062	Gasket				
25	1	58040027	Crankshaft				
26	1	61070070	Key				
27	2	61070068	Spacer				
28	1	61070076	Bearing				
29	2	61070073	Plug				
30	1	61070074	Seal ring				
31	1	4162265	Support				
32	1	58040328	Clutch case				
33	4	3819005R	Washer				
34	1	61070090R	Spring				
35	1	61070091AR	Clutch				
36	1	58040327AR	Clutch driver				BT6-067-09/09
37	1	61370257	Kit pin + Belleville washer + spacer ring				
38	1	58040345	Deflector				
39	1	3064034	Washer				
40	1	58042169	Labels kit				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61070012R	Cable				
2	1	072700036A	Grommet				
3	1	094600097AR	Spark plug cap				
4	1	094600169A	Spring				
5	1	3055104R	Spark plug				
6	2	006000085	Screw				
7	2	3819005R	Washer				
8	2	3916004R	Washer				
9	1	58040344AR	Ignition coil				
10	3	3960064AR	Screw				
11	1	093500397	Starter handle				
12	1	072700089R	Bushing				
13	1	61070036R	Spring				
14	1	61070019AR	Starter rope				
15	1	58040019BR	Pulley				
16	1	094600451	Washer				
17	1	3960070AR	Screw				
18	4	3801013R	Screw				
19	4	3916005R	Washer				
20	1	58042002BR	Starter assy				
21	1	3980012	Nut				
22	2	4161151	Pin				
23	2	58040003	Pawl				
24	2	58040004	Spring				
25	1	58040350R	Flywheel				
26	1	58040395R	Filter kit				BT6-061-07/08
27	1	56510064R	Filter				BT6-061-07/08
28	1	61070003ER	Filter support				BT6-061-07/08
29	2	61052009BR	Screw				
30	1	58040341R	Tank				
31	2	61040020	Bushing				BT6-061-07/08
32	1	2318847R	Carburetor WYJ-442				
33	2	3801047	Screw				
34	1	61070004	Insulator				
35	1	61070007	Gasket				
36	1	4161438	Gasket				
37	1	61070006R	Gasket				
38	1	58040343R	Complete cap				
39	1	4161211R	Bush				
40	1	61070011AR	Breather valve				
41	1	61070078R	Tube				
42	1	61110034R	Tube				
43	1	094600450R	Fuel filter				
44	1	61110162B	Bushing				
45	1	58040354	Tube				
46	4	3918005	Washer				
47	1	006000829	Washer				
48	1	58040395R	Filter kit				BT6-061-07/08
49	1	58040396R	Filter				BT6-061-07/08




■ 6 **KIT RIPARAZIONE
REPAIR KIT**

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318815	Pump body assy				
2	1	2318703	Washer				
3	2	2318580	Screw				
4	1	2318813	Support				
5	1	2318812	Jet				
6	1	2318674	Repair kit				
7	1	2318571	Cover				
8	1	2318572	Primer pump				
9	4	2318585	Screw				
10	1	2318592	Valve				
11	1	2318701	O-ring				
12	1	2318577	Adjuster nut				
13	1	2318570	Primer body				
14	1	2318189	Ring				
15	1	2318902	Valve				
16	1	2318568	Spring				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	W58040032	Half grip left				
2	1	W58040033	Half grip right				
3	1	W58040034	Throttle lever				
4	1	W58040035	Lever				
5	1	W58040036	Lever				
6	1	W58040037	Pin				
7	1	W58040038	Throttle rod				
8	1	W58040039	Switch				
9	1	W58040040	Throttle cable				
10	1	W58040041	Spacer				
11	1	W58040042	Spring				
12	1	W58040043	Spring				
13	1	W58040044	Spring				
14	5	W58040045	Screw				
15	1	W58040046	Support left				
16	1	W58040047	Support right				
17	2	W58040048	Spacer				
18	2	W58040023R	Nut				
19	2	W58040050	Gasket				
20	1	W58040051	Front handle				
21	1	W58040052	Hand guard				
22	2	W58040053R	Screw				
23	2	W58040054R	Spacer				
24	3	W58040055	Screw				
25	2	W58040056R	Screw				
26	4	W58040057R	Spring support				
27	2	W58040058R	Spring				
28	2	W58040059R	Spring				
29	4	W58040025	Screw				
32	2	W58040063	Support				
33	2	W58040064	Washer				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	4	W58040002	Screw				
3	1	W58040003	Upper case				
4	1	W58040004R	Clutch drum				
5	1	W58040005	Sprocket				
6	2	W58040006	Plate				
7	1	W58040007R	Bearing				
8	3	W58040008R	Bearing				
9	1	W58040009	Nipple				
10	4	W58040010	Screw				
11	1	W58040011	Cover				
12	1	W58040012	Chain sprocket				
13	2	W58040013R	Connecting rod				
14	1	W58040014	Felt				
15	1	W58040015	Blade guide 600mm				
16	2	W58040016R	Blade 600mm				
17	1	W58040082	Guard				
18	1	W58040018	Plate				
19	1	W58040019	Ring				
20	6	W58040002	Screw				
21	3	W58040021R	Screw				
22	1	W58040022	Screw				
23	4	W58040023R	Nut				
24	4	W58040024R	Washer				
25	1	W58040025	Screw				
26	2	W58040026	Screw				
27	2	W58040027	Nut				
28	1	W58040028	Guard				
29	1	W58040029	Bracket				