








Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	4153069AR	Starter case				
2	1	3801015R	Screw				
3	3	3819006R	Grower				
4	7	3916005R	Washer				
5	1	3078009	Washer				
6	1	4191020A	Starter handle				
7	1	004000132R	Spring				
8	1	4138438BR	Pulley				
9	1	4151225	Flange				
10	1	3960111	Screw				
11	1	4098073R	Starter rope				
12	4	3960056R	Screw				
13	1	4151135	Support				
14	5	3914003R	Nut				
15	3	3801009	Screw				
16	2	4161151	Pin				
17	2	4138441R	Pawl				
18	2	4161186A	Spring				
19	1	4138446AR	Flywheel				
20	1	3912009	Nut				
21	1	3916008R	Washer				
22	2	3050009	Seal ring				
23	2	094000006R	Bearing				
24	1	4098232R	Key				
25	1	3037013	Bearing				
26	1	4100311	Crankshaft				
27	1	4179087A	Cable				
28	1	4138722R	Ignition coil				
29	1	005000019	Spark plug				
30	1	4098064R	Spark plug cap				
31	3	3801010R	Screw				
32	2	3801003	Screw				
33	2	3819005R	Washer				
34	2	3916004R	Washer				
35	2	61050046R	Piston ring				
36	2	004900061R	Ring				
37	1	4179036R	Piston pin				
38	1	4100330A	Piston assy Ø36				
39	1	4100334A	Cylinder				
40	4	3801014	Screw				
41	4	3833073R	Washer				
42	1	4098869R	Short block				
43	1	4151106	Plate				
44	2	3806044	Screw				
45	1	4095211R	Plate				
46	1	4098465A	Muffler cover				
47	1	4095036R	Gasket				
48	1	007200859	Screw				
49	1	4159122A	Muffler				
50	1	4151097	Support				
51	1	4175080R	Screw				
52	1	3819010	Washer				
53	1	3918006	Washer				




48 ■ KIT RIPARAZIONE
REPAIR KIT




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	4098030R	Gasket				
2	1	4151134	Deflector				
3	1	4174087AR	Gasket				
4	1	4159184	Throttle cable				
5	1	4174150R	Insulator				
6	2	3819006R	Grower				
7	2	3801015R	Screw				
8	1	4174093AR	Gasket				
9	1	4098377R	Band				
10	1	4159008	Tube				
11	1	2318520R	Carburetor C1Q-E3				
12	1	4161177	Starter lever				
13	1	4159102	Support				
14	1	3833073R	Washer				
15	1	4120070	Washer				
16	2	3801012	Screw				
17	1	4161178	Shutter				
18	1	4161176R	Filter				
19	1	3760018	Screw				
20	1	4161174	Cover				
21	1	3801013R	Screw				
22	2	3918010R	Washer				
23	4	4138302	Washer				
24	1	094600450R	Fuel filter				
25	5	3914003R	Nut				
26	1	4159204AR	Fuel tank				
27	1	072700358	Tube				
28	1	4162268R	Bushing				
29	1	4151258R	Complete cap				
30	1	4098658AR	Breather valve				
31	1	4100308AR	Gasket				
32	2	3801066	Screw				
33	1	4159003	Flange				
34	6	3801011	Screw				
35	1	4159005	Clutch drum+hub				
36	2	4138494	Spring				
37	4	3918007	Washer				
38	2	4138375	Bushing				
39	2	3806040	Screw				
40	1	4138376R	Clutch				
41	1	4138374A	Clutch driver				
42	1	4151044	Tube				
43	1	3059002	Band				
44	1	4159205	Tube				
45	1	4162270A	Fittings				
46	1	074000239	Screw				
47	1	074000147	Cover				
48	1	2318671	Repair kit				
49	1	074000139	Cover				
51	1	003300036	Fittings				
52	1	095000164	Ring				
53	1	2318592	Valve				
54	1	2318569	Screw				
55	1	2318191	Cover				
56	4	035000162	Screw				
57	1	093500115	Spring				
58	1	2318606	Screw H				
59	1	093500269	Screw L				
60	1	035000165	Spring				
61	1	072700347	Spring				
62	1	375100086	Shaft				
63	1	2318211	Pin				
64	1	003300209	Screw				
65	1	072700211	Shutter				
66	1	094600148	Spring				
67	1	074000240	Adjust. screw				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
68	1	003300201	Spindle				
69	1	2318572	Primer pump				
70	1	035000152	Needle				

DA OTTOBRE 1995
 FROM OCTOBER 1995
 DEPUIS OCTOBER 1995
 DESDE OCTUBRE 1995



FINO A SETTEMBRE 1995
 TILL SEPTEMBER 1995
 JUSQU'A SEPTEMBRE 1995
 HASTA SEPTIEMBRE 1995



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	4159057	Screw				
2	1	4159058	Handle				
3	2	4159059	Nut				
4	1	4159055	Plate				
5	1	4159056	Half crankcase				
6	1	4159063	Nipple				
7	1	4159039	Clamp				
8	1	3960012	Screw				
9	1	4159198	Switch				
10	1	4159040	Pin				
11	1	4159042	Throttle lever				
12	1	4159043	Ring				
13	1	4159197	Lever				
14	1	4159045	Spring				
15	1	4159046	Button				
16	2	4159048	Screw				
17	1	4159190A	Handlebar				
18	1	3801012	Screw				
19	1	3912004	Nut				
20	1	4159099	Screw				
21	1	4159190A	Handlebar				
22	1	61040131R	Handle				
23	1	4159191	Guard				
24	1	034000013	Nut				
25	4	3914006R	Nut				
26	1	4159062	Slide				
27	1	3914003R	Nut				
28	2	4159071	Screw				
29	1	3035023R	Bearing				
30	1	3035038R	Bearing				
31	1	4159066	Sprocket				
32	1	4159193	Shaft				
33	1	4159044	Pin				
34	1	4159049	Screw				
35	2	4159069	Connecting rod				
36	1	4159032	Guard				
37	1	4138359R	Button				
38	1	3918010R	Washer				
39	1	3819006R	Grower				
40	1	3801066	Screw				
41	1	4159224	Blade				
42	1	4159224	Blade				
43	4	4159080	Washer				
44	4	4159081	Screw				
45	2	4159082	Screw				
46	1	4159073	Screw				
47	1	4159077	Plate				
48	1	4159074	Felt				
49	1	4159076	Gear case				
50	5	4159078	Screw				
51	4	4159079	Screw				
52	3	3960021	Screw				
53	1	4159127	Ring				
54	3	3960029	Screw				
55	1	4159006	Throttle cable				
56	1	4100098BR	Spring				
57	1	58040034	Handlebar				
58	1	4138361R	Spring				
59	1	4174245CR	Throttle lever				
60	1	4138360R	Spring				
61	1	4138358R	Button				
62	2	3801016R	Screw				
63	1	4159199	Spring				
64	1	4174246AR	Lever				
65	1	2317021R	Switch				
66	1	4159184	Throttle cable				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
67	1	4190015A	Cable				