





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56552011A	Piston assy				BT6-075-10/10
2	2	3801068R	Screw				
3	1	56550030AR	Muffler				BT6-068-10/09
4	1	56550033R	Deflector				
5	1	3055101	Spark plug				
6	4	3801047	Screw				
7	2	3916004R	Washer				
8	2	61170014	Spacer				
9	2	093000167	Ring				BT6-075-10/10
10	1	072700045R	Piston pin				BT6-075-10/10
11	2	61050046R	Piston ring	SN 5303120928			BT6-075-10/10, BT6-086-05/13
12	1	56552012B	Complete cylinder	SN 5303120928			BT6-075-10/10, BT6-086-05/13
13	1	56550126R	Starter case				
14	2	3050022AR	Seal ring				
15	2	3034009R	Bearing				
16	2	074000267AR	Spacer				
17	1	072700046R	Bearing				
18	1	4098232R	Key				
19	1	56550008R	Crankshaft				
20	1	56550064AR	Crankcase				
21	1	56552018B	Short block	SN 5303120928			BT6-075-10/10, BT6-086-05/13
22	2	012000028	Screw				BT6-068-10/09
23	1	56550119R	Deflector				BT6-068-10/09
24	1	56550155R	Gasket				BT6-068-10/09




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56550050R	Retainer washer				
2	1	50070123R	Starter rope				
3	1	56550049R	Starter handle				
4	1	004000132R	Spring				
5	1	56550022R	Starter pulley				
6	1	56550021R	Shaft joint				
7	1	3027005R	Ring				
8	1	56520040AR	Plate				
9	1	3918020R	Washer				
10	1	3801010R	Screw				
11	1	56552016	Starter assy				
12	4	3918010R	Washer				
13	2	3960091AR	Screw				
14	1	3801013R	Screw				
15	1	3819006R	Washer				
16	1	3916005R	Washer				
17	2	3078009	Washer				
18	3	3960121R	Screw				
19	2	56550102R	Plate				
20	2	3960011R	Screw				
21	1	3960100R	Screw				
22	1	56550180R	Cap and spring				
23	1	3911009R	Nut				
24	1	56550145BR	Ignition coil		SN 5300189931		BT6-073-07/10
25	1	56550134R	Flywheel		SN 5300189931		BT6-073-07/10
26	1	56550182AR	Ignition coil	SN 5300189932			BT6-073-07/10
27	1	61320057AR	Flywheel	SN 5300189932			BT6-073-07/10
28	1	56550121AR	Slide control				BT6-063-10/08
29	1	56550122R	Plate				
30	1	3960121R	Screw				
31	1	56550190R	Cable		SN 5300189931		BT6-073-07/10
32	3	56550102R	Plate				
33	1	56550190R	Cable	SN 5300189932			BT6-073-07/10
34	1	3801007	Screw				
35	1	006000315R	Washer				
36	1	3916004R	Washer				

I° Serie / I° Series




Esauriti: Sostituiti dal kit pos. 6 /
Out of stock: Replaced by kit ref. 6




I° Serie / I° Series






II° Serie / II° Series




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56550115R	Gasket				
2	2	61200021AR	Gasket				
3	1	2318776CR	Carburetor WT-904				
5	2	56550044R	Bushing				BT6-074-07/10
6	1	56552007AR	Filter support				BT6-074-07/10
7	2	3833073R	Washer				
8	2	3801012	Screw				
9	1	56550208R	Air filter	SN 5303201057			BT6-087-06/13
10	1	56550040R	Filter		SN 5303201056		BT6-087-06/13
12	1	56550043AR	Starter lever				BT6-074-07/10
13	1	56550114R	Insulator				
14	1	61070006R	Gasket				
15	1	61070079AR	Tank cap				
16	1	2318817R	Air purge				
17	1	56550071R	Tube				
18	1	56550070R	Tube				
19	1	61070011AR	Breather valve				
20	1	56550069R	Tube				
21	1	094600450R	Fuel filter				
22	1	4098377R	Band				
23	1	4161211R	Bush				
24	1	56550068R	Tube				
25	1	56550191R	Cover				BT6-074-07/10
26	1	56550192R	Starter lever				BT6-074-07/10
27	1	56560079R	Deflector				
28	1	56550203R	Filter	SN 5301157352	SN 5303201056		BT6-080-05/11, BT6-087-06/13
29	1	56550210R	Air filter kit	SN 5303201057			BT6-087-06/13




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56550006R	Fan				
2	1	56550057R	Knife				
3	1	3911009R	Nut				
4	1	56550004R	Right cover				
5	1	56550072R	Spring				
6	4	3918010R	Washer				
7	20	3960091AR	Screw				
8	1	56550026R	Lever				
9	1	56550050R	Retainer washer				
10	1	56550147R	Engine cover				
11	1	56550025R	Stop lever				
12	1	56550023AR	Throttle				
13	1	56550024R	Throttle cable				
14	1	56550046AR	Handle				BT6-065-01/09
15	2	56550048R	Stand				
16	1	56550047R	Handle				
17	2	3960122R	Screw				
18	1	56550034R	Complete support				
19	1	56550003R	Left cover/tank				
20	1	56550156R	Button				
22	1	56550175R	Guard				
23	1	56550123R	Pin				
24	4	3960100R	Screw				
25	1	56510050R	Washer				



Optional



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56550073R	Tube				
2	1	56550127R	Tube				
3	1	56552002	Blower/vacuum tube with duckbill end section				
4	1	3960121R	Screw				
5	1	56552014	Labels kit				
6	1	56552010R	Tool kit				
7	1	56550075R	Elbow				
8	1	56550078AR	Grassbag				
9	1	56550077R	Tube				
10	1	56550076AR	Tube				
11	1	56552001A	Suction kit				
12	1	56550179	Anti-shock cable kit				BT6-065-01/09



■ 13 KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	003300197	Screw				
2	1	2318777	Cover				
3	1	094600148	Spring				
4	1	074000240	Adjust. screw				
5	1	50010141	Screw				
6	1	375100078	Shutter				
7	2	095000164	Ring				
8	1	2318211	Pin				
9	1	2318737	Shaft				
10	1	072700347	Spring				
11	1	2318779	Screw L				
12	1	2318191	Cover				
13	1	2318671	Repair kit				
15	4	035000162	Screw				
16	1	2318778	Adjust. screw				
17	1	003300201	Spindle				
18	1	003300202	Screw				