
XH-PCM150-08B Gearbox Assy parts list



	Stand	
01	Oil Seal	3003001
02	Oil Seal	3003002
03	Housing	3003003
04	Bearing	3003004
05	Drive Shaft	3003005
06	Bearing	3003006
07	Drive Shaft	3003007
08	Key	3003008
09	Key	3003009
10	Gear	3003010
11	Locating Bush	3003011
12	Housing	3003012
13	Washer	3003013
14	Filler Plug	3003014
15	Bolts	3003015
16	Level Plug	3003016
17	Drain Plug	3003017
18	Gasket	3003018
19	Bearing	3003019
20	Gear	3003020
21	Drive Shaft	3003021
22	Bearing	3003022